Raspberry Pi 3A+/B/B+/4/4B

SensiML Supported Development Kits		
 **Raspberry Pi 3rd Gen Board**  **Raspberry Pi 4th Gen Board**	**Processor**	3rd Gen: Broadcom* BCM2837x, quad-core Arm* Cortex* A53 4th Gen: Broadcom* BCM2711, quad-core Arm* Cortex* A53
	Pre-enabled Sensor Types	None
	Additional Available Sensors ⓘ	Adapter boards available for sensor integration
	Available External Sensor Interfaces	UART, I2C, SPI
	Pre-enabled Connectivity	None
	Programming Environment	Compilers: Arm GCC Compiler
	Firmware Flashing	Raspberry Pi uses on-board bootloader flash to run an OS installed on an SDCard.
	SensiML Knowledge Pack Formats	Library, C Source
	Useful Links	SensiML Getting Started Guide, HW Quick Start Guide

* All product and company names are property of their respective holders. Use of them does not imply any affiliation with or endorsement by them.

Copyright © 2022 SensiML Corporation. All rights reserved.